

Configuration Data Sheet

00806-0100-4727, Rev UB

December 2010

Rosemount 8700 Series

Rosemount 8700 Series Configuration Data Sheet

All sections up to C1 Note are required on this form.

★ = Default Value

☐ Select only one of the items provided

☐ One or more of the listed items can be selected

Customer Information

Customer: _____ Contact Name: _____
P.O./Reference No: _____ Fax No./Email: _____
Phone No.: _____ P.O. Line Item: _____
Quote No. _____ Model No.: _____
Customer Signoff: _____

Tagging

Hardware Tag.: _____ (21 characters max)
Software Tag: _____ (8 characters max)

Meter

Model Type: ☐ Sensor ☐ Magmeter System (Sensor and Transmitter) ☐ Transmitter
Transmitter Type: ☐ Integral Mount ☐ Remote

Fluid Selection

Liquid: ☐ Water ☐ Acetic Acid ☐ Nitric Acid ☐ Orange Juice Concentrate ☐ Milk ☐ Other⁽¹⁾

Custom: Name: _____
Density or Specific Gravity⁽²⁾: _____
Conductivity: _____

(1) Requires Custom information below.

(2) Required for Mass Units only.

Process Information⁽¹⁾

	Units	Minimum	Normal	Maximum	Design
Flow Rate:					
Pressure:					
Process Temp:					

(1) Gray boxes are required values.

Process Variable Configuration

	LRV ⁽¹⁾ (0.0 ft./sec★)	URV ⁽²⁾ (30 ft/sec★)	Unit of Measure	
Flow:				(Not available in FOUNDATION fieldbus)

(1) Note that the LRV for the Process Variable that is mapped to the PV will determine the 4 mA set point of the transmitter.

(2) The URV for the Process Variable that is mapped to the PV will determine the 20 mA setpoint of the transmitter.

ROSEMOUNT®

www.rosemount.com


EMERSON™
Process Management

Rosemount 8700 Series

C1 NOTE

The following sections are required only if C1 option is selected.

Basic Configuration

Damping = 2.0 seconds★ (2.0 seconds for FOUNDATION fieldbus)
 Sensor Size = _____ 3-in.★ 3 to 36-in. (8712H) / 0.15 to 60-in. (All others)

Special Units (HART only)

For a list of all standard configurable units, consult the appropriate product manual available on www.emersonprocess.com/rosemount.

Volume Units: _____ (4 characters)

Base Units: ☐ Gallons ☐ Cubic Meters ☐ Barrels ☐ Short Ton ☐ Kilogram
☐ Liters ☐ Cubic Centimeters ☐ Barrels (beer) ☐ Pound ☐ Imperial Gallon
☐ Feet ☐ Cubic Feet ☐ Metric Ton
☐ Meters

Conversion Factors: _____ where one special unit = Conversion Factor x Base Unit

Time Base: ☐ Seconds ☐ Minutes ☐ Hours ☐ Days

Rate Units: _____ (4 characters)

Totalizer Units: _____ (4 characters) Totalizer Units can be set independently of the flow units

HART / Transmitter Information

Write Protect ☐ Off★ ☐ On
 Alarm Option ☐ High★ ☐ Low (8732E/8712E only)
 Alarm Standard ☐ Rosemount★ ☐ Namur

Descriptor _____ (16 characters maximum) Date (day/month/year): ____ / ____ / ____

Message _____ (32 characters maximum)

☐ 4–20 mA, scaled pulse, and auxiliary output with simultaneous digital signal based on HART® protocol★
☐ Burst mode of HART digital process variable

Burst mode output options:

- ☐ Primary variable in engineering units.
☐ Primary variable in percent of range.
☐ All dynamic variables in engineering units.
☐ All dynamic variables in engineering units and the primary variable mA value.

☐ Multidrop Communications⁽¹⁾

Choose transmitter address (1-15)⁽²⁾ _____

(1) This option fixes the transmitter's analog output at 4 mA.

(2) Default transmitter address is 1 if multidrop communication is selected.

Sensor Information (Data Only – Does Not Affect Transmitter Output)

Sensor Tag No. (Software) _____ (8 characters maximum)

Sensor Serial No. _____ (7 characters maximum)

Sensor Calibration No. _____ 16 Digits from sensor 1000005010000000★

SST Sensor Tag No. _____

Enter either the Rosemount sensor model number or select one option from each of the following groups of options:

Sensor Model No. _____

Electrode Material:

☐ 316 SST★ ☐ Tantalum
☐ Titanium ☐ Platinum-Iridium
☐ Nickel Alloy-276 ☐ Special

Electrode Type:

☐ Standard★ ☐ Standard, plus Grounding
☐ Bullet ☐ Special

Flange Material:

☐ Carbon Steel★ ☐ 304 SST
☐ 316 SST ☐ Special

Liner Material:

☐ PTFE★ ☐ Neoprene ☐ Ryton
☐ ETFE ☐ Natural Rubber ☐ Special
☐ Polyurethane

Configuration Data Sheet

00806-0100-4727, Rev UB

December 2010

Rosemount 8700 Series

Advanced Configuration Options (Not Required for Typical Start-up)			
Pulse Scaling: (Not available in FOUNDATION fieldbus) <input type="radio"/> 0.03 ft [★] <input type="radio"/> 1 Pulse = _____ units Pulse Width: _____ 1.5 m/s [★]		Operation Mode: <input type="radio"/> Normal [★] <input type="radio"/> Filter Signal Processing: <input type="radio"/> Off [★] <input type="radio"/> On _____ 90 [★] No. Samples _____ 2 [★] Max.% Limit % _____ 2 [★] Time Limit Sec	
Low Flow Cutoff: _____ 0.04 ft/sec [★]		Coil Pulse Mode: (Not available with 8712H) <input type="radio"/> 5 Hz [★] <input type="radio"/> 37.5 Hz	
Local Display Language: (8732E only) <input type="radio"/> English [★] <input type="radio"/> Spanish <input type="radio"/> French <input type="radio"/> German <input type="radio"/> Portuguese			
Flowrate Display (Not available in FOUNDATION fieldbus)		<input type="radio"/> Eng Units and % span [★] <input type="radio"/> Eng Units and Gross Total <input type="radio"/> % Span and Gross Total	
Totalizer Display (Not available in FOUNDATION fieldbus)		<input type="radio"/> Net and Gross [★] <input type="radio"/> Forward and Reverse	
Analog Loop Power		<input type="radio"/> Internal [★] <input type="radio"/> External (8732E/8712E only)	
Pulse Loop Power (8732E only)		<input type="radio"/> Internal [★] <input type="radio"/> External [★]	
Simulate (FOUNDATION fieldbus only)		<input type="radio"/> Off [★] <input type="radio"/> On	
Standard Diagnostics Information			
Empty Pipe <input type="radio"/> Enable <input type="radio"/> Disable [★]		Trigger Level _____ 100 [★] (8732E/8712E only) Empty Pipe Counts _____ 5 [★] (8732E/8712E only)	
Electronics Temperature (8732E/8712E only) <input type="radio"/> Enable <input type="radio"/> Disable [★]			
Advanced Diagnostics Information (Requires DA1/D01 Option) (8732E/8712E only)			
High Process Noise <input type="radio"/> Enable [★] <input type="radio"/> Disable	Grounding/Wiring Faults <input type="radio"/> Enable [★] <input type="radio"/> Disable	NOTE If DA1/D01 is selected in the model code, Empty Pipe and Electronics Temp Diagnostics will also be enabled.	
8714i Meter Verification Diagnostic (Requires DA2/D02 Option) (8732E/8712E only)			
Test Criteria Empty Pipe: _____ 5% [★] Flowing Full: _____ 5% [★] Full, No Flow: _____ 5% [★]		NOTE The Test Criteria value sets the pass fail value for the meter calibration verification check. This value must be an integer value between 1 and 10%.	
Continuous Meter Verification (8732E only)			
Test Criteria _____ 5% [★]	Transmitter <input type="radio"/> Enable [★] <input type="radio"/> Disable	Coil <input type="radio"/> Enable [★] <input type="radio"/> Disable	Electrode Resistance <input type="radio"/> Enable <input type="radio"/> Disable [★]
			Analog Signal <input type="radio"/> Enable [★] <input type="radio"/> Disable
Digital Input / Digital Output Information (Requires AX Option) (8732E/8712E only)			
DI/DO Channel 1 <input type="radio"/> Input [★] <input type="radio"/> Output <input type="radio"/> Disable Digital Input Configuration <input type="radio"/> Positive Zero Return (PZR) [★] <input type="radio"/> Totalizer Reset <input type="radio"/> Transmitter Reset		DO Channel 2 <input type="radio"/> Enable [★] <input type="radio"/> Disable DO Configuration (Select 2 options if channel 1 is configured as a DO) <input type="checkbox"/> Reverse Flow <input type="checkbox"/> Flow Limit 1 <input type="checkbox"/> Zero Flow <input type="checkbox"/> Flow Limit 2 <input type="checkbox"/> Transmitter Fault (Alarm) <input type="checkbox"/> Diagnostic Status Alert <input type="checkbox"/> Empty Pipe <input type="checkbox"/> Totalizer Limit 1	

Rosemount 8700 Series

Flow and Totalizer Alert Configuration (8732E/8712E only)

Flow Limit 1 Configuration

Control 1 ☐ ON ☐ OFF

Mode 1 ☐ > High Limit

☐ < Low Limit

☐ In Range

☐ Out of Range

High Limit 1: _____

Low Limit 1: _____

Flow Limit Hysteresis: _____

Flow Limit 2 Configuration

Control 2: ☐ ON ☐ OFF

Mode 2: ☐ > High Limit

☐ < Low Limit

☐ In Range

☐ Out of Range

High Limit 2: _____

Low Limit 2: _____

Totalizer Limit Configuration

Control: ☐ ON ☐ OFF

Mode: ☐ > High Limit

☐ < Low Limit

☐ In Range

☐ Out of Range

High Limit: _____

Low Limit: _____

Totalizer Limit Hysteresis: _____

Diagnostic Status Alert (8732E/8712E only)

☐ Electronics Failure

☐ Coil Open Circuit

☐ Empty Pipe

☐ Reverse Flow

☐ Grounding / Wiring Fault

☐ High Process Noise

☐ Electronics Temp Out of Range

☐ Continuous Meter Verification

*Select as many options as needed for the application

Diagnostic Analog Alarm Configuration

Analog Output to Alarm

☐ Enable

☐ Disable★

☐ Empty Pipe★

☐ Reverse Flow

☐ Grounding and Wiring

☐ High Process Noise

☐ Electronics Temperature Out of Range

☐ Totalizer Limit Alert

☐ Flow Limit 1 Alert

☐ Flow Limit 2 Alert

☐ Continuous Meter Verification

Standard Terms and Conditions of Sale can be found at www.rosemount.com/terms_of_sale

The Emerson logo is a trademark and service mark of Emerson Electric Co.

Rosemount and the Rosemount logotype are registered trademarks of Rosemount Inc.

All other marks are the property of their respective owners.

Emerson Process Management

Rosemount Inc.

8200 Market Boulevard
Chanhassen, MN 55317 USA
T 1-800-999-9307
T (International) (952) 906-8888
F (952) 949-7001

www.rosemount.com

Emerson Process Management Flow

Neonstraat 1
6718 WX Ede
The Netherlands
T +31 (0)318 495555
F +31(0) 318 495556

Emerson FZE

P.O. Box 17033
Jebel Ali Free Zone
Dubai UAE
Tel +971 4 811 8100
Fax +971 4 886 5465

Emerson Process Management

Singapore Pte Ltd.
1 Pandan Crescent
Singapore 128461
Tel (65) 777-8211
Fax (65) 777-0947
Enquiries@AP.EmersonProcess.com